


# REMOTE CONTROL LAYOUT

- 1 TV Input Source Select
- 2 TV/AUX Power/Standby
- 3 Shortcut Buttons:
  - Recordings
  - Replay
  - Movies
  - Launch WiFi TV
- 4 Shows
- 5 Playback Controls
- 6 Menu
- 7 Navigation & OK
- 8 Back
- 9 Volume Up & Down
- 10 Channel Select & Text Entry
- 11 Information
- 12 Search
- 13 Infra-red (IR) Window
- 14 Microphone
- 15 STB Power/Standby
- 16 Guide Filter
- 17 Settings
- 18 Recording Wizard
- 19 Electronic Program Guide
- 20 Home
- 21 Voice Control
- 22 Channel/Page Up & Down
- 23 Mute
- 24 Subtitles/Closed Captions
- 25 Last Channel Recall
- 26 Low Battery Warning LED



888.992.7844  
[arvig.com/WiFiTV](http://arvig.com/WiFiTV)



**NOTE:** The buttons on this remote are universal in function, however, the options available within the Arvig app may be different than within other apps. Your remote may vary. Item 258